740 SERIES ORAL TUBE

GENERAL CHARACTERISTICS

- Designed for applications requiring a durable connection to either a film or a coated fabric
- Large oval sealing flange maximizes bonding strength
- High flow for easy top off and oral inflation
- Smooth radius allows maximum flow while protecting the life vest fabric integrity
- Available in polyurethane
- Available in red or black
- Available in three lengths:
 - o 4.31 inches (10.95 cm)
 - o 5.53 inches (14.05 cm)
 - o 6.75 inches (17.1 cm)
- Approvals:
 - o UL 1191 recognized for PFD's
 - Meets Cen/ISO 12402-7 standard
 - HRC certified to TSO-C13 FAA



740 ORAL TUBE WITH CAP

PERFORMANCE CHARACTERISTICS

- Opening pressure (crack) 0.44 psi max
- Flow rate Minimum 100 lpm at 1 psig
- Functions at temperature ranges of 32°F to 120°F
- Storage temperature range -22°F to 158°F
- Pull out force (per UL 1191) 100 lb

PART NUMBERS

- 740ROLS43 4.31 inches
- 740ROLS56 5.53 inches
- 740ROLS66 6.75 inches
- 740ROLSxxC4 with Cap
- 740ROLSxxBK Black

TOOL NUMBERS

- D747N Sealing Die
- T740 Valve Extractor
- TV74703G Inflate/Deflate Adapter

MATERIALS

- Polyether Urethane
- Acetal
- Silicon
- Stainless steel
- Aluminum

QUALITY CRITERIA

- 100% tested for crack pressure
- 100% tested for leaks

SERVICE INSTRUCTIONS

See IFU 740-1 Rev. B

PACKAGING AND SHIPPING

- Box size: 10 inch x 15 inch x 11 inch
- Parts per box: 200/250 (tube length variance)
- Minimum shipping: one box